

DECUS NO.

8-602A

TITLE

THE PDP-8 COOKBOOK, VOLUME 1

AUTHOR

Floor Anthoni

COMPANY

Medical Biological Laboratory TNO Rijswijk, The Netherlands

DATE

January 1973

SOURCE LANGUAGE

PAL

ATTENTION

This is a USER program. Other than requiring that it conform to submittal and review standards, no quality control has been imposed upon this program by DECUS.

The DECUS Program Library is a clearing house only; it does not generate or test programs. No warranty, express or implied, is made by the contributor, Digital Equipment Computer Users Society or Digital Equipment Corporation as to the accuracy or functioning of the program or related material, and no responsibility is assumed by these parties in connection therewith.

THE PDP8 COOKBOOK

BY

FLOOR ANTHONI

Medical Biological Laboratory TNO, Rijswijk 2100, The Netherlands

SUBJECT: Subroutine standardisation

INTRODUCTION:

By the beginning of 1972, nearly 14 000 computers of the PDP8 family have been produced and field-installed. All of them have to be programmed to fulfill the tasks, dedicated to them.

The small size of most PDP8 configurations has forced most programmers to program the machine in assembly language. Many programs have since then found their way to the DECUS PROGRAM LIBRARY. The typical application-oriented programs, however, were rarely submitted to the LIBRARY, because nobody would ever be likely to apply for them. The experience, accumulated elsewhere, was therefore not available to others.

In programming the PDP8 computer. I have experienced the usefulness of program modularity at the assembly level. The basic
modules are, in effect, subroutines that perform a certain
function, and that have been programmed in such a way, that they
can be used as "recipies" in a cookbook. When these "recipies"
are being sent to a central editor, and published regularly,
they will accumulate experience into a common module library,
THE PDP8 COOKBOOK, available to others.

This paper proposes a norm for modules, submitted to the library.

The subroutine jump certainly is the most powerful instruction of any computer. It enables the programmer to avoid duplication of code, and to build hierarchical structures of software intelligence, increasing the semantic power of each free location in core.

Subroutines in hierarchical structures will in general do the task expected from them, with a minimum of "directions" given from "above". They can, themselves, set lower level subroutines to work for them, also with a minimum of directions. These directions are in general, information, that has to be transferred down to the subroutine. The subroutine can, on the other, hand, send information back. Subroutines that can be directed to do many tasks, will, in general need more "instructions" from above. The programmer has to consider this aspect with great care. The following remarks on the ways, information can be sent to and from subroutines may assist him in this respect.

When only one parameter, needs to be transferred, use the ACCU-MULATOR. The LINK can be used as additional YES or NO information, although it is, in general not frequently used. The use of other registers, like the MULTIPLIER-QUOTIENT register, must be strongly dissuaded, because the module will then not be able to run on many machine configurations.

More information can be transferred as arguments, following the **J**MS instruction. This is especially useful for parameters that can be set at assembly time, or that need not to change very often. Use the AC for frequently changing information. A common information area in page Ø can also be used. This is especially useful when those parameters need to be accessed by many modules. (For example program— and buffer—limits, pointers, etc.). The main problem of the sharing of the same storage locations, by

different subroutines, is that extreme care must be exerted when calling subroutines within those subroutines.

All subroutine modules in the COOKBOOK will be provided with the storage locations they need, in order to avoid conflicting use of these locations.

Another way to circumvent such problems is to employ the techniques of reentrant and recursive programming, in which pushdown list structures are being used. This aspect will not be within the scope of this paper. The concept of creating an information "vector", that is a limited area in core with all the information, in order that only the pointer to this "vector" needs to be transferred, is, however, very useful for transfers, both in and out of the subroutine.

HOW TO PREVENT UNWANTED INTERFERENCE

When using subroutines, that have been used before, the most likely assembly error is that illegal redefinitions will result from the duplicate use of symbols. Therefore care must be taken to label a location. The following conventions are proposed: use very few tags. Put all storage locations and other items in front of the subroutine entry, that needs to have more than 3 characters. All other tags need to share, at least the first 3 characters of the subroutine entry.

Those programmers that want to "pack" subroutines into the least possible space, will find it easy to modify the subroutines in this respect.

DOCUMENTATION

Simple subroutines need less documentation than the more sophisticated ones. Comments should be inserted, wherever additional

information is needed. Avoid trivial comments like CLA/CLEAR AC, but express the general concept and thoughts, as if it were a flow chart. The documentation must be adequate for the reader to easily understand how the subroutine works. For more sophisticated routines a flow chart is a must. Each subroutine must have a compact functional description of not more than one line (52 characters). Then follows a general description of the subroutine and an example of its use. All program lines and comment lines should not exceed 52 positions, as assembler output and cross-reference numbers must have room to be inserted.

The source tape should be submitted with the tabulations, not being converted to spaces.

The listing should preferably be made with a teletype printer (teletype type of character), printed with tabs converted to spaces. Use a clean typing head and a new black ribbon, as the listing will be offset-copied. Drawings and flow-charts should be drawn with black ink, or taped with special stickers.

For the use of symbols, the reader is referred to Appendix I.

PROGRAM SUBMISSION

Submit your program subroutine to

The Editorial Board of
The PDP8 COOK BOOK
c/o Floor Anthoni,
Medical Biological Laboratory TNO,
139, Lange Kleiweg,
RIJSWIJK (ZH),2100,

The Netherlands.

NOTE! It is of vital importance that errors are reported back to the authors or the editorial board. Only by doing so one can achieve the highest reliability of the published subroutines.

COOKBOOK VOLUME 1 CATALOG LISTED BY NUMBER

- 001 Type the characters following the JMS instruction
- 002 Teletype type routine with overlap
- 003 Type a character chain
- 004 Binary to decimal conversion, single prec.no sign
- 005 Binary to octal conversion, no sign.fixed field
- 006 High speed reader subroutine
- 007 Tabulator routine
- 008 Move a block through core
- 009 Binary punch with field setting, checksum, leader
- 010 PAL message printer
- 011 General branch routine
- 012 Check AC if octal
- 013 Logical operators, AND, OR, NAND, NOR, EXCL.OR, etc.
- 014 PS8/OS8 option decoder
- 015 Print 2 digits in decimal
- 016 Print the PS8/0S8 date
- 017 Print the AC as a FOCAL linenumber
- 018 Print 4 decimal digits, using routine 015, no sign
- 019 Read a decimal number in core
- 020 Decimal print, leading blanks, no sign
- 021 Print double length decimal, no sign
- 022 Octal print, no sign, leading spaces
- 023 Double word octal print using 022
- 024 Translate TELEX code to ASCII
- 025 Translate TELEX code to ASCII
- 026 Translate ASCII code to TELEX
- 027 Interrupt ASCII output handler with rotating buffer
- 028 Device interrupt handler (part of 027)

- 029 Read or write DECtape in both directions
- 030 Subroutine to pack a fixed buffer in core (300 chars) into a fixed output buffer (200 chars) in TSS8 packed format
- 031 Pack characters into a buffer in TSS8 format, one by one
- 032 As 031, but with a fixed allocated buffer
- 033 Unpack TSS8 format packed buffer into an output buffer
- 034 Unpack TSS8 format packed buffer, one character at a time
- 035 Subroutine to read a 6 character name in core
- 036 Search a file name in DN blocks (Disk monitor)
- 037 Search for an unused block in SAM block, and reserve it for the current file
- 038 Search internal file number in SAM blocks (Disk Monitor)
- 039 Subroutine to read or write on disk (TSS8).

LIST OF CONTRIBUTORS

Floor Anthoni Medisch Biologisch Laboratorium TNO, Lange Kleiweg 139,

Rijswijk (ZH),

The Netherlands

Contributions

1, 2, 3, 4, 5, 6, 7, 9, 9, 10, 11, 12, 13, 14,

15, 17, 18

Thierri den Dunnen

Dr. Neher Laboratorium,

St.Paulusstraat 4,

Leidschendam,

The Netherlands

19, 20, 21, 22, 23, 24, 25,

26, 27, 28, 29, 30, 31, 32,

33, 34, 35, 36, 37, 38, 39

Hans Mees,

Prins Maurits Laboratoria, C.D.,

Lange Kleiweg 137,

Rijswijk (ZH),

The Netherlands

8

Paul Lohman,

Medisch Biologisch Laboratorium TNO,

Lange Kleiweg 139,

Rijswijk (ZH),

The Netherlands

16

FLOW-CHART conventions

1

The flow-charts make use of relatively few symbols:

	Entry, or exit of a program or sub-program, also used for the inter-connection of flow-charts on different pages.
discontacting by their handsterman	Trow-charts on different pages.
and control as well as a superior of the control as a superior of the cont	A rectangle describes one or more program steps.
	Decision, branching
	Subroutine call. A subroutine may have more than one return
management to humanistic at the con-	(branching).
/COMMENT	Comments appear behind a slash (/).
START,	Used to name program ties in agreement
LOOP,	with the listings.

```
7001 TYPE THE CHARACTERS FOLLOWING THE JMS INSTR-
/TERMINATOR IS A ZERO.
        JMS TYPTEX
                         /TYPL "ABC"
                         /"A"
        301
                         /"B"
        302
        303
                         /"C"
        Ø
                         /TERMINATOR
           RETURN
                         /AC=∅
TYPTEX, 0
        TAD I TYPTEX
                         /GET CHAR.
        ISZ TYPTEX
        SNA
                         /ZEEO?
        JMP I TYPTE*
                         /YES.JMP TO NEXT LOC.
        JMS TYPE
                         INO. TYPE
        JMP TYPTEX+1
```

```
/C/2 TELETYPE TYPE FOUTINE
ZINITIALIZES WHEN ENTERED FOR FIRST TIME.
/ YOU RESTARTABLE !
/
     - TAD CHARACTER
       JMS TYPE
          RETURN
                      /AC=∅
       NOP
TYPE
       Ø
       JMP •+3
                     /OVERLAID BY "NOP"
       TSF
       JMP •-1
       TLS
       CLA
       TAD TYPE-1
       DCA TYPE+1
       JMP I TYPE
```

```
ZOMS TYPE A CHARACTER CHAIN
/TYPE THE CHARACTERS IN THE LIST, POINTED TO
VEY THE FIRST ARGUMENT. LIST TERMINATOR =0
       JMS TYPTEX
                        /TYPE "ABC"
          LIST
           RETURN
                        /AC=Ø
/LIST.
        301
        302
        303
        Ø
        Ø
                        /USED AS POINTER
TYPTEX, 0
                        /TYPE TEXTSTRING
        TAD I TYPTEX
                        /GET ARG
        DCA TYPTEX-1
                        /SAVE TO USE AS POINTER
        ISZ TYPTEX
                        /FOR CORRECT RETURN
        TAD T TYPTEX-1
                        /GET CHAR
        SNA
                        ZERO?
        JMP I TYPTEX
                        YES, RETURN
        JMS TYPE
                        /NO
        ISZ TYPTEX-1
        JMP TYPTEX+4
                        /LOOK FOR NEXT
```

```
7004 FINARY TO DECIMAL CONVERSION AND TYPE; NO SIGN
VEOUTINE TO CONVERT A BINARY WORD TO DECIMAL AND TYPE IT.
/VALID FOR NUMBERS 0-4095. NO SIGN.
VIE USED FOR 3 DIGITS: DELETE 6030; -4=-3 DIGIT COUNT.
1
        TAL WORD
        JMS PRINTD
           FETURN
                         /AC=Ø
        6030
                         /-1000 CONVERSION CONSTANTS
        7634
                         1-100
                         /-10 .
        7766
        7777
                         /-1
                         /USED FOR CONV. CONSTANTS
        TAD .
                         /DIGIT ECL TO BE TYPED
        Ø
                         /COUNTER
        260
                         /TO MAKE A CHAR.
                         /SAVE AREA
        0
                         /DIGITS TO BE TYPED (-4,-3,-2)
PRINTD, 0
                         /ENTER WITH WORD IN AC
        DCA PRINTD-2
        TAD PRINTU-1 /SET UP COUNT
        DCA PRINTD-4
        DCA PRINTD-5
TAD PRINTD-6
TAD PRINTD-4

ZEY ADDING COUNT TO TAD
        DCA •+1
        HL T
        CLL
                         /VALUE - CONSTANT
        TAD PRINTD-2
        SNL
                         /OVERFL OW?
        JMP .+4
                         /NO, TYPE IT
        ISZ PRINTD-5
                         YES, NEXT TRY
        DCA PRINTD-2
        JMP PRINTD+5
        CLA
        TAD PRINTD-5
                        /BCD
        TAD PRINTD-3
                         7+260
        JMS TYPE
        ISZ PRINTD-4
        JMP PRINTD+4
                        VNEXT DIGIT
        JMP I PRINTD
```

```
1005 BINARY TO OCTAL CONVERSION AND PHINT
/ROUTINE PRINTS THE AC IN OCTAL, NO, SIGN.
/
        TAD WORD
        JMS PRINT8
           RETURN
                        /AC=∅
        260
        7
                         /MASK
        0
                         /DIGIT COUNTER
                         /# OF DIGITS
        -4
        Ø
                         /TEMP ORARY
PRINTS, Ø
        RAL CLL
        DCA PRINT8-1
        TAD PRINT8-2
        DCA PRINT8-3
                       /SET UP COUNT
        TAD PRINT8-1
        RAL
        RTL
        DCA PRINT8-1
        TAD PRINT8-1
        AND PRINT8-4
                        ZMASK
        TAD PRINT8-5
                        /MAKE ASCII
        JMS TYPE
                         74 DONE?
        ISZ PRINT8-3
                        NOT YET
        JMP PRINT8+5
        JMP I PRINT8
```

```
/006 HIGH SPEED READER SUBROUTINE
VENTER WITH AC=0; ROUTINE INITIALIZES HSE. EACH HEENTHY
/AFTER AN END-OF-TAPE CONDITION (TIME-OUT)
/ JHEN STOPPED IN TAPE MOTION IT SIGNALS TIMEOUT THE
VNEXT ENTRY. THE ROUTINE HAS A BUILT-IN TIMING LOOP
/THAT TIMES OUT IF THE READER IS NOT SWITCHED ON,
/OR IF THE READER LOOSES ITS FLAG BY RUNNING OUT OF TAPE.
/
        JMS HSREAD
        OUT OF TAPE RETURN
        NORMAL RETURN, CHAR. IN AC
                        /USED AS TIME-OUT COUNT
                        ZENTRY
HSREAD, 0
                        /SET UP COUNT
        DCA HSREAD-1
                        /FLAG SIGNALS TO INIT READER
HSRFLG, 1
        TAD HSRFLG
                        /THESE INSTR. CONTRIBUTE TO LOOP
        SZA CLA
        JMP .+3
                        /INIT READER
        RSF
                        /SKIP?
        JMP •+5
                        /NO, COUNT TIME-OUT
        DCA HSRFLG
                        /CLEAR FLAG
        6016
                        /READ
        ISZ HSREAD
                        /RETURN, CHAR IN AC
        JMP I HSREAD
        ISZ HSREAD-1
        JMP HSRFLG
        ISZ HSRFLG
                       /SET FLAG TO SIGNAL TIMEOUT
        JMP I HSREAD /EOT RETURN
```

```
7007 TABULATOR ROUTINE
/THE USER HAS TO TAKE CARE OF:
VINCREMENTING TABONT WITH EACH INCOMING CHARACTER, CLEARING
/IT JHEN CARRIAGE RETURN. TAR-INTERVAL IS VARIABLE.
/A JMS TO TAB WILL MOVE THE TYPING HEAD TO THE NEXT
/TABULATOR POSITION.
/
       CLA
       JMS TAB
         RETURN
                      /AC=0
TABONT, Ø
       -10
                        ZIAB INTERVAL
       240
                        /SPACE
TAB,
       0
                        /ENTER WITH AC =0
       TAD TABONT
                        /SUBTRACT N TIMES TO GIVE REMAINDER
       TAD TAB-2
       SMA
       JMP .-2
       DCA TABONT
                     /USE AS NEGATIVE COUNTER
       TAD TAB-1
       JMS TYPE
       ISZ TABONI
                       /READY?
       JMP •-3
       JMP I TAB
                      /YES
```

```
ZOOS SUPPOUTING TO MOVE A PLOCK THROUGH CUEL
        CALLING SEQUENCE
                JMS MOVE
                   BEGINADDRESS
                   ENDADDHESS
                   DESTINATION OF FIRST WORD
                RETURN /AC=0
        IF BEGINABURESS AND ENDADDRESS ARE
          THE SAME ADDRESS, OR REGINADDRESS
          IS GELATER THAN ENDADDRESS.
          NO MOVE IS PERFORMED
        IF BEGINADDRESS AND DESTINATION ARE
          THE SAME ADDRESS, A COMPLETE MOVE
          IS PERFORMED: YOU SHOULD BE LESS STUPID!
        56 (OCTAL) CORE LOCATIONS ARE USED
        0
        0
        0
MOVE
        TAD I MOVE
                        /GET BEGINADDRESS
        DCA MOVE-1
        ISZ MOVE
        TAD I MOVE
                        /GET ENDADDRESS
        DCA MOVE-2
        ISZ MOVE
        TAD MOVE-2
        CMA
        TAD MOVE-1
                        /CALCULATE WORDCOUNT
        SNA
                        /IS IT POSITIV OR ZERO?
        JMP MOVRET
                       YES, NO MOVE NEEDED
        DCA MOVE-4
                       /SAVE WORDCOUNT
        TAD MOVE-1
        CIA CLL
        TAD I MOVE
                        /CALCULATE MOVECOUNT
        DCA MOVE-3
                      /AND SAVE
        SZL
                        /LINK IS ON IF MOVE TO HIGHER CORE
        JMP •+3
                        /SKIP NEXT INSTRUCTIONS
        IAC CML
                        /LINK IS OFF
        TAD MOVE-4
                        VEIRST IN ADDRESS IS BEGINADDRESS
        TAD MOVE-2
        DCA MOVE-S
                        /SAVE INPUTPOINTER
        SZL
                        VSKIP IF MOVE TO LOWER CORE
        CLL CMA HAL
                        /TO HIGHER CORE, INC = -1
        IAC
        DCA MOVE-1
                        /SAVE INCREMENT
        TAD MOVE-2
                        /SET UP OUTPUTPOINTER
        TAD MOVE-3
        DCA MOVE-3
                        VAND SAVE
MVLOOP, TAD I MOVE-2
                        /GET A WORD
        DCA I MOVE-3
                        VAND STORE IT IN DESTINATION BLOCK
        TAD MOVE-2
        TAD MOVE-1
                        VINCREMENT INPUTPOINTER
        DCA MOVE-2
        TAD MOVE-3
```

	TAD MOVE-1	ZINCHEMENT OUTPUTPOINTER
	DCA MOVE-3	·
	ISZ MOVE-4	/INCREMENT WORDCOUNT
	JMP MVLOOP	/AGAIN IF NOT ZERO
/		
MOVRET,	ISZ MOVE	/SET UP RETURNADDRESS
	JMP I MOVE	/HETUKN

```
2009 BINARY PONCH WITH FIELD SETTING
 ITHREE SUBBOUTINES TO PUNCH AN AREA OF CORE IN BINARY
/LOADER FORMAT. FIELD SETTINGS AND OFIGIN SETTINGS
 VARE BEING PUNCHED AT EACH ENTRY: CHECKSUM IS PUNCHED
/ WHEN PUNCHK IS CALLED.
 ITHE ROUTINE CAN TAKE DATA FROM A DIFFERENT FIELD.
VIT CAN OPERATE IN ALL FIELDS. SEVERAL USES APPLY:
 /1) NORMAL USE. THE DATA IS LOCATED IN THE SAME FIELD OR
 /STRANGE FIELD. ENTER WITH FIELD IN AC; LINK=0
 /2) THE CODE IS IN SAME FIELD AS BINPUN, ONLY A DIFFERENT
/FIELD SETTING NEEDS TO BE PUNCHED. ENTER BINPUN
/WITH FIELD IN AC AND LINK=1.
/3) THE CODE HAS BEEN MOVED IN CORE. THE FIRST LOCATION
VIS NOT NECESSARILY THE ORIGIN. NOW ENTER BINPUN WITH
/AC=FIELD FOR SETTING; LINK=1; SET ORIGIN UNEQUAL TO
/FIRST LOCATION IF THIS IS TRUE.
/EXAMPLE OF NORMAL USE:
        JMS LEADER
                     PUNCH LEADER, CLLAR CHECKSUM
        CLL
        TAD (0010
                        /FIELD 1
        JMS BINPUN
           ORIGIN
                        VIN NORMAL USE=FIRST LOC.
           FIRST LOC.
           LAST LOC.
        JMS PUNCHK
                        PUNCH CHKSM AND TRAILER
BINEND. 0
                        /LAST LOC. TO PUNCH
        6201
        100
        300
                        /FOR FIELD SETTING
        0
                        /TEMP . STORAGE
BINPUN.
        Ø
        DCA BINPUN-1
        SZL
                        /SET UP DF IF LINK=0
        JMP BIN3
        TAD BINPUN-1
        TAD BINPUN-4 /MAKE CDF
BIN3,
        DCA BIN2
        TAD BINPUN-1
                        /MAKE FIELD SETT. AND PUNCH
                        VNOTE! ₩ IELD SETT. NOT IN CHECKSUM!!
        TAD BINPUN-2
        JMS TYPE
        TAD I BINPUN
                        /GET ORIGIN
        ISZ BINPUN
        DCA BINPUN-1
        TAD BINPUN-1
                        VPUNCH ORIGIN
        JMS BINLH
                        /LEFT HALF
        TAD BINPUN-3
                        /+100 FOR ORIGIN
        JMS BINCHK
        TAD BINPUN-1
                        /RIGHT HALF AND PUNCH
        AND BINLH-1
        JMS BINCHK
        TAD I BINPUN
                        /SET UP POINTER
        DCA BINPUN-1
        ISZ BINPUN
        TAD I BINPUN
                        /GET END
        DCA BINEND
BIN2,
        CDF Ø
                        /OVERLAID BY CDF STRANGE FIELD
        TAD I BINPUN-1, /GET DATA
        JMS BINLH
                        PUNCH LEFT HALF
```

```
JMS BINCHK
        TAD I BINPUN-1 /PUNCE RIGHT HALF
        AND BINLH-1
        JMS BINCHK
        TAD BINEND
                         /END REACHEL?
        CIA
        CLL.
        TAD BINPUN-1
        ISZ BINPUN-1
        SNL CLA
                        /NO, TAKE NEXT DATA
        JMP BIN2+1
                         /YES, RESTORE DF
        RIF
        TAD BINPUN-4
        DCA • † 1
        CDF Ø
                         /OVERLAID
        ISZ BINPUN
        JMP I BINPUN
        SPA CLA
/GET LEFT HALF OF THE AC
        77
BINLH.
        Ø
        RTR
        RTR
        RTR
        AND BINLH-1
        JMP I BINLH
/UPDATE THE CHECKSUM, AND PUNCH FRAME
                       /CHECKSUM
BINCHK, Ø
                        VENTER WITH 6 BIT FRAME IN AC
        DCA BINLH
                        /USE BINLH TEMPORARILY
        TAD BINLH
        TAD BINCHK-1
                        /UPD. CHKSM
        DCA BINCHK-1
        TAD BINLH
        JMS TYPE
        JMP I BINCHK
PUNCH 100(8) LEADER OR TRAILER HOLES; CLEAR CHECKSUM
        200
LEADER, 0
        TAD BINPUN-3 /USE CHKSM AS NEG COUNT
        CIA
        DCA BINCHK-1
        TAD LEADER-1
        JMS TYPE
        ISZ BINCHK-1
                        /READY?
        JMP --3
                        N0
        JMP I LEADER
                        /YES
/PUNCH CHECKSUM; PUNCH THAILER; CLEAR CHECKSUM
PUNCHK, Ø
        TAD BINCHK-1 /GET CHECKSUM
        JMS BINLH
        JMS TYPE
        TAD BINCHK-1
        AND BINLH-1
        JMS TYPE
                        /CLEARS CHECKSUM
        JMS LEADER
```

19

JMP I PUNCHK

```
1010 PAL MESSAGE PRINTER
/PRINTS A MESSAGE CODED WITH THE PAL PSEUDO-OP
/'TEXT'. PAL3 AND PAL8 COMPATIBLE
/
        JMS PRMESG
        MESG
        RETURN /AC=0
/MESG, TEXT 'ABC82' /CODED AS 0102;0370;6200
        77
                        /MASK
        -40
                        /TO TEST
        240
                        /TO MAKE ASCII
        100
                        /TO MAKE ASCII
                        /PACKSWITCH Ø=LEFT; 7777=R
                        /POINTER
        (1)
PRMESG, Ø
        CMA
                        /SAVE POINTER(-1)
        TAD I PRMESG
        DCA PRMESG-1
        ISZ PRMESG /FOR RETURN
PRM1,
        CMA
        DCA PRMESG-2 /PACKSW=RIGHT ISZ PRMESG-1 /NEXT WORD
        TAD I PRMESG-1 /FETCH AND ROTATE 6
        RTR
        RTR
        AND PRMESG-6 /MASK 6 BITS
PRM2.
        SNA
        JMP I PRMESG
                       ZERO ENDS THE LIST
                       /< 40 ?
        TAD PRMESG-5
        SPA
        TAD PRMESG-3 /YES ASCII 301-337 TAD PRMESG-4 /NO, ASCII 240-277
        JMS PRINT
        ISZ PRMESG-2 /LEFT OR RIGHT?
        JMP PRM1
                       /LEFT
        TAD I PRMESG-1 /RIGHT
        JMP PRM2
```

```
/011 GENERAL BRANCH ROUTINE
VERANCH ROUTINE BRANCHES ACCORDING TO THE CONTENTS
/OF THE AC. COMPARED TO EACH ITEM OF A LIST.
/EXIT FROM BRANCH IS ALWAYS WITH AC=0
       TAD AC
       JMS BRANCH
         LIST-1
       RETURN IF NOT IN LIST (AC=0)
/LIST.
      212
                      /IF "CHAR"=212, PROGRAM JUMPS TO "LF"
       LF
       215
       CR; ETC; ETC .....
                       VO IS LIST TERMINATOR!!!!!!
       Ø
                       ZAC
                       /BRANCH POINTER
       Ø
                       ¥ENTER WITH ARGUMENT IN "CHAR"
BRANCH, Ø
       DCA BRANCH-2
       TAD I BRANCH
       ISZ BRANCH
                       /INIT POINTER
       DCA BRANCH-1
BRANC.
       ISZ BRANCH-1
       TAD I BRANCH-1 /FETCH ELEMENT FRM LIST
                      /END OF LIST?
       SNA
       JMP I BRANCH /YES
       CIA
       TAD BRANCH-2
       ISZ BRANCH-1
       SZA CLA
       JMP BRANC
                      /NO TRY NEXT
       TAD I BRANCH-1 /YES, GO TO IT
       DCA BRANCH
       JMP I BRANCH
```

```
7012 CHECK IF OCTAL
PROUTINE CHECKS WHETHER THE AC IS AN OCTAL LIGIT.
/
       TAD CHARACTER
       JMS OCTCHK
        NOT OCTAL RETURN /AC=0
         OCTAL RETURN
                               /AC=∅
       1 Ø
        -270
OCTCHK, Ø
       TAD OCTCHK-1
       SMA
       JMP OCTS
       TAD OCTCHK-2
       SPA CLA
       JMP I OCTCHK
       ISZ OCTCHK
OCTS. CLA
       JMP I OCTCHK
```

```
1013 LOGICAL OPERATORS ON TWO NUMBERS
ITHE RESULT OF LOGICAL OPERATIONS IS IN THE AC.
                         A 1010
/AND (MASKING)
                         B 1100
                         = 1000
        TAD A
        AND B
                         A 1010
/INCLUSIVE OR
/SETS BITS B IN A
                         B 1100
                         = 1110
/
        TAD A
        CMA
        AND B
        TAD A
                         A 1010
/CLEAR BITS B IN A
                         B 1100
                         = 0010
1
        TAD B
        CMA
        AND A
                         A 1010
/N OF
                         B 1100
/
                         = 0001
        TAD A
        CMA
        DCA TEM
        TAD B
        CMA
        AND TEM
                         A 1010
/NAND
                         B 1100
                         = 0111
        TAD A
        AND B
        CMA
                         A 1010
/EXCLUSIVE OR
                         B 1100
                         = 0110
        TAD A
        AND B
        CMA
        DCA TEM
        TAD A
        AND TEM
        TAD B
        AND TEM
```

```
/014 PS8-05/8 OPTION DECODER
/CHECKS THE OPTION, SPECIFIED IN THE AC AND CAUSES
/A RETURN, DEPENDING ON WHETHER THE OPTION HAS BEEN
/SET
/OPTIONS IN OS8 RESIDE IN FIELD 1 LOC 7643-7645:
/7643 A B C D E F G H I J K L ASCII 301-314
/7644 M N O P Q R S T U V W X ASCII 315-330
77645 Y Z Ø 1 2 3 4 5 6 7 8 9 ASCII 331,332,260-271
       TAD (16
                      /CHECK OPTION 16 (N)
       JMS OPTION
          OPTION NOT SET RETURN/AC=Ø
          OPTION SET RETURN /AC=0
OPTM1.
       7777
       -14
                       /-12(10)
       7642
                       /POINTER
                       /TEMP . STORAGE
       7642
                       /COUNTER, ALSO POINTER
OPTION, Ø
                       VENTER WITH POSITION IN AC
       DCA OPTION-2
       TAD OPTION-3 /RESTORE COUNTER
       DCA OPTION-1
       TAD OPTION-2
                      /SUBTRACT 12 TO FIND WORD
       TAD OPTION-4
       ISZ OPTION-1
       SMA SZA
       JMP --3
       TAD OPTM1
                       /FOR L AND X
       DCA OPTION-2
                       /SAVE REMAINDER MODULO 12
       CLL CML
                       /AND ROTATE ONE BIT INTO POSITION
       RAL
                       VROTATE FURTHER
       ISZ OPTION-2
       JMP .-2
       CDF 10
                       /AND WITH OPT WORD FIELD 1
       AND I OPTION-1
       CDF Ø
       SZA CLA
       ISZ OPTION
                      /IN CASE IT HAD BEEN SET
       JMP I OPTION
```

```
/015 PRINT TWO DIGITS IN DECIMAL
/THE VALUE OF THE AC IS PRINTED IN TWO DIGITS
/CORRECTLY IF < 99(DECIMAL).
1
        TAD (VALUE
        JMS PRNT2
        RETURN
                       ∕AC=Ø
        860
                       /TO MAKE ASCII
        -12
                       /10 DECIMAL
                       /TEMP STORAGE
        Ø
        0
                       /COUNTER
PRNT2,
        DCA PRNT2-2
                    TRY SUBTRACT 10 UNTIL OVFLO
        TAD PRNT2-2
        TAD PENT2-3
        SPA
        JMP •+3
        ISZ PRNT2-1
                      /SUBTRACT FURTHER
        JMP PRNT2+1
        CLA
        TAD PRNT2-1
                     PRINT HIGH ORDER DIGIT
        TAD PRNT2-4
        JMS PRINT
        TAD PRNT2-2
        TAD PRNT2-4
        JMS PRINT
       DCA PRNT2-1
                      /RESET COUNTER
       JMP I PRNT2
```

```
/016 PRINT THE PS8-OS8 DATE
/THE DATE IS PRINTED AS: 07/17/72
ITHE ROUTINE MAKES USE OF PENTS, TO TYPE TWO
/DECIMALS. REQUIRES ROUTINES PENTS AND PRINT.
/DATE IN OS8 IS STORED IN LOC 7666, FIELD 1:
/7666 MMMMDDDDDYYY /M=MONTH, D=DAY, Y=YEAR
      JMS DATE
       RETURN
                       /AC=Ø
        7
                        /MASKS
DA TM.
        17
        37
       257
                       /SLASH
       106
                       170 YEARS
                       /STORAGE
       Ø
                       /DATE LOC. IN OS8
        7666
DATE
       CDF 10
                       /PICK TH E DATE
        TAD I DATE-1
       CDF Ø
       DCA DATE-2
       TAD DATE-2
       CLL RTL
                       /SHIFT MONTH OUT
       RTL
       RAL
       AND DATM+1
                       /AND (17
       JMS PRNT2
       TAD DATE-4
                       ✓PRINT SLASH
       JMS PRINT
       TAD DATE-2
       RTR
                        /SHIFT MONTH OUT AND PRINT
       RAR
       AND DATM+2
       JMS PRNT2
       TAD DATE-4
                       /SLASH
       JMS PRINT
       TAD DATE-2
                       NOW THE YEAR
       AND DATM
       TAD DATE-3
                       1+70
       JMS PRNT2
```

JMP I DATE

```
/017 PRINT THE AC AS A FOCAL LINENUMBER
/THE VALUE OF THE AC IS PRINTED AS IN FOCAL:11.35
/XX.YY STORED AS FOLLOWS: XXXXXYYYYYYY IN 1 WORD.
/IF YYYYYY>99 STRANGE DIGITS OCCUR AS IN FOCAL.
/REQUIRES ROUTINES PRNT2 AND PRINT.
        TAD VALUE
        JMS PRNTF
       RETURN
                       /AC=Ø
PRNTFM, 37
                        /MASKS
        177
        256
                       /PERIOD.
                       /STORAGE
PRNTF.
        DCA PRNTF-1
                    /ISOLATE AND PRINT HIGH ORDER
        TAD PRNTF-1
        CLL RTL
        RTL
        RTL
        AND PRNTFM
                      /AND (37
        JMS PRNT2
        TAD PRNTF-2
        JMS PRINT
        TAD PRNTF-1
                      /NOW LOW ORDER
       AND PRNTFM+1
       JMS PRNT2
       JMP I PRNTF
```

```
1018 PRINT 4 DECIMAL DIGITS USING ROUTINE PRNT2
/THE CONTENT OF THE AC IS DIVIDED BY 100(10)
/GIVING TWO LOW ORDER DIGITS AND 2 HIGH ORDER.
/THESE ARE PRINTED BY PRNT2.
        TAD VALUE
        JMS PRNT4
        RETURN
                        /AC=0
        7634
                        /-100(10)
        Ø
                        /STORAGE AND LOW ORDER
        Ø
                        VHIGH ORDER COUNTER
PRNT4.
        DCA PRNT4-2
        CLL
                        /TRY TO SUBTRACT 100 UNTIL OVERFLOW
        TAD PRNT4-2
        TAD PRNT4-3
        SNL
        JMP •+3
        ISZ PRNT4-1
        JMP PRNT4+1
        CLA
        TAD PRNT4-1
                        PRINT HIGH ORDER DIGITS
        JMS PRNT2
        TAD PRNT4-2
                        PRINT LOW ORDER DIGITS
        JMS PRNT2
        DCA PRNT4-1
                       /RESET COUNTER
        JMP I PRNT4
```

```
Z019 SUBROUTINE READS A DECIMAL NUMBER FROM KEYFL
/RUBOUT REMOVES NUMBER COMPLETELY
/CALL : JMS DECINE
        RETURN WITH NUMBER BINARY IN AC
DECINP.0
         CLA
         DCA DECNUM /CLEAR REGISTER
                         /READ CHAR FROM KEYBOARD
         JMS READ
         TAD CHAR
         JMS PRINT
                          PRINT THAT CHAR
         TAD CHAR
                          /GET CHARACTER
                          /IS IT RUBOUT?
         TAD M377
         SNA CLA
         JMP DECINP+1 /YES READ ALL OVER AGAIN
                          NO.
         TAD CHAR
         TAD M260
         SPA
                          /CHAR>=260?
        JMP DECOUT /NO, CHARACTER IS DELIM
TAD M12 /YES
SMA CLA /CHAR<272?
JMP DECOUT /NO, CHAR IS DELIMETER
TAD DECNUM /YES, CHAR IS FIGURE
                          /NO, CHARACTER IS DELIMETER
         CLL RAL
         DCA DECTMP
                          /NUMB.*2
         TAD DECTMP
         RTL
                          /NUMB*8
         TAD DECTMP
                          /NUMB*8+NUMB*2=NUMB*10
         TAD CHAR
                          /ADD LAST FIGURE
         TAD M260
         DCA DECNUM
                         /DECIMAL NUMBER
         JMP DECINP+3
DECOUT, CLA
        TAD DECNUM
        JMP I DECINP /EXIT
/VARIABLES
DECNUM. Ø
DECTMP. Ø
/GENERAL CONSTANTS
M12, -12
M260.
        -260
M377, -377
```

```
/020 DECIMAL PRINT ROUTINE,
/PRINTS AC DECIMAL IN 4 DIGITS
/MAX NUMBER = 4095 DECIMAL
/SKIPS LEADING ZERO'S
DPRT.
        DCA DPRREG
                      /SAVE AC IN PRINTREG.
                      /GET INSTRUCTION
        TAD DPRINS
        DCA DPRPTP
                       /PUT INSTR. ON POINTER
        TAD M4
        DCA DPRFAC
                      /4 DIGITS
                       /CLEAR PRINT Ø FLAG
        DCA DPRFL
        DCA DPRFIG
                       /CLEAR DIGIT
DPRSUB, CLL
        TAD DPRREG
                       /PICK UP SAVED AC
DPRPTP, TAD DPRTEN
                       /SUBTRACT POWER OF TEN
                       /REMAINDER POSITIVE?
        SNL
        JMP •+4
                      /NO, PRINT DIGIT
        DCA DPRREG
                      YES, SAVE REMAINDER
        ISZ DPRFIG
                       /DIGIT:=DIGIT+1
        JMP DPRSUB
                       VREPEAT SUBTRACTION
        CLA CLL
        TAD DPRFIG
                       /GET DIGIT
        SNA
                       /A ZERO?
        JMP DPRZRO
                       /YES
DPRIN, TAD C260
                       /NO, CONVERT TO ASCII
       JMS PRINT
       ISZ DPRFL
                       MAKE NOT EQUAL Ø
DPRINI, ISZ DPRPTP
                       /MODIFY INSTR ON DPRPTP
       ISZ DPRFAC
                       /PRINTED 4 DIGITS?
       JMP DPRSUB-1
                      /NO, PRINT NEXT DIGIT
       JMP I DPRT
                       YES, RETURN
DPRZRO, TAD DPRFL
       SZA CLA
       JMP DPRIN
       JMP DPRIN1
DPRREG. Ø
DPRFL. Ø
DPRINS, TAD DPRTEN
DPRFAC.0
DPRFIG. Ø
DPRTEN, 6030
              /-1000
       7.634
              /-100
              1-10
       7766
       7777
/GENERAL CONSTANTS
M4, -4
C260, 260
```

```
1021 SUBROUTINE TO PRINT DOUBLE LENGTH DECIMAL
/CALL: JMS DDECPR
       MOST SIGNIFICANT PART
        LEAST SIGNIFICANT PART
        NUMBER OF DIGITS TO BE PRINTED ( <=8 )
        RETURN
DDECPR. 0
        TAD I DDECPR
                        /FETCH MOST SIGNIFICANT PART
        DCA DDX
                         /SAVE
        DCA DDPD
                        /CLR NUMB. OF PRINTED DIGITS
        ISZ DDECPR
        TAD I DDLCPR
                        VEETCH LEAST SIGNIFICANT PART
        DCA DDX+1
                         /SAVE
        ISZ DDECPR
        TAD I DDECPR
                        /FETCH FORMAT
        DCA DDNDIG
        ISZ DDECPR
                        /CORRECT RETURN
                        /ADDRESS 10-POWER LOW
        TAD DDATPL
                        /POINTER 10-POWER LOW
        DCA DDPTPL
        TAD DDATPH
                        /ADDRESS 10-POWER HIGH
        DCA DDPTPH
                        /POINTER 10-POWER HIGH
        TAD MIØ
        DCA DDNFAC
                        /FACTORISE 8 DIGITS
                        /CLEAR DIGIT
        DCA DDIGIT
DDSUB. CLL
        TAD DDX+1
                        /L SIGNIFIC PART OF NUMB.
        TAD I DDPTPL
                       /LOW PART FACTOR
        DCA DDX+1
                        /STOEE
                        /OVERFLOW IN AC
        RAL
        TAD DDX
                        M SIGNIFIC PART OF NUMB.
        TAD I DDPTPH
                        /HIGH FACTOR
        SNL
                        /RESULT NEGATIVE?
        JMP •+4
                        /YES
        DCA DDX
                        /STORE RESULT OF SUBTRACTION
        ISZ DDIGIT
                        /NO. STEP UP DIGIT
        JMP DDSUB
                        /SUBTRACT 2-LENGTH AGAIN
        CLA
                        /CLEAR BEFORE CORRECTION
        TAD I DDPTPL
                        /10-POWER LOW
        CIA
                        /MINUS
                        /CORRECT LAST SUBTRACTION
        TAD DDX+1
        DCA DDX+1
                        /STORE
        TAD DDIGIT
                        /GET DIGIT
        SZA
                        /=Ø?
        JMP DDPDIN
                        NO
        TAD DDPD
                        /ALREADY PRINTED?
        SZA CLA
       JMP DDPDIN
                        /YES
       IAC
       TAD DDNFAC
       SMA CLA
                        /ALL DI#D0= 0?
       JMP DDPDIN
                        YES
       TAD DDNFAC
                        INEGATIVE VALUE
       TAD DDNDIG
                        POSITIVE VALUE
       SPA CLA
                        /SPACE?
       JMP DDPTIN
       TAD C240
                        YES
       JMP DDFPR
```

```
DDPDIN, ISZ DDPD
                         /CONVERT TO ASCII
        TAD C260
DDFPR. JMS PRINT
                         /PRINTIDIGIT
                        ISTEP UP POINTER LOW
DDPTIN, ISZ DDPTPL
                        /STEP UP POINTER HIGH
        ISZ DDPTPH
                        /READY FACTORIZE?
        ISZ DDNFAC
        JMP DDSUB-1
                        /NO, NEXT DIGIT
        TAD DDPD
        CIA
        TAD DDNDIG
        SPA SNA CLA
        JMP •+3
        TAD DDNDIG
        DCA DDPD
        CLL
                        /EXIT, END PUNCHOUT ROUTINE
        JMP I DDECPR
/CONSTANTS PUNCH OUT ROUTINE
DDATPL, DDTPL
DDA TPH. DDTPH
DDP TPL. Ø
DDP TPH. Ø
DDX.
      Ø
        Ø
DDNFAC. Ø
DDIGIT. Ø
DDTPL.
       4600
        6700
        4540
        4360
        6030
        7634
        7766
        7777
DDTPH.
        3166
        7413
        7747
        7775
        7777
        7777
        7777
        7777
DDP D.
DDNDIG, Ø
/GENERAL CONSTANTS
M10.
       -10
        240
C240,
C260.
        260
```

```
1022 OCTAL PRINT ROUTINE
/NONSIGNIFICANT ZERO'S BECOME SPACES
1
       CLA
       DCA OCTFIG /CLEAR FLAG FIGURE PRINTED
/
       DCA OCTSPC
                       /CLEAR SPACE-COUNTER
        TAD NUMBER
/CALL :JMS OCTPRT / WITH NUMBER IN AC / RETURN AC=0 /IF NUMBER=0.
/OCTSPC=4, = # OF SPACES TO PRINT
/ IF NUMBER IS ZERO, OCTSPC=4 IS #SPACES TO PRINT
OCTPRT, 0
        RAL '-
                       PROTATE IN LINK
                      /TEMP . STORAGE
        DCA OCTIMP
        TAD M4
                       74 OCTADES
        DCA OCTONT
OCTPRØ, TAD OCTTMP
        RAL
        RTL
        DCA OCTTMP
                       /STORE RESULT
                      /GET IT BACK
        TAD OCTTMP
        AND C7
                       MASK OCTADE
        SNA CLA
                       ZERO ?
                      /YES
        JMP OCTZER
        TAD OCTSPC
                       /NO SPACES TO PRINT?
        SNA
        JMP OCTNUM
                       /NO. GO PRINT FIGURE
        CIA
                       YES, SET COUNTER
        DCA OCTSPC
        TAD C240
        JMS PRINT
                       /PRINT THE SPACES
        ISZ OCTSPC
        JMP .-3
OCTNUM, CLA IAC
                       /SET FLAG FIG. PRINTED
        DCA OCTFIG
        TAD OCTTMP
        AND C7
OCTOPR, TAD C260
                       MAKE THE FIGURE
       JMS PRINT
OCTPRI, ISZ OCTCNT
                       /READY?
        JMP OCTPRØ
                       /N 0
        JMP I OCTPRT
                       YYES, EXIT .
OCTZER, TAD OCTFIG
        SZA CLA
                       /FIGURES PRINTED ?
        JMP OCTØPR
ISZ OCTSPC
                       YES, PRINT THIS ZERO TOO
                       /NO COUNT AS SPACE
        JMP OCTPRI
OCTTMP, Ø
OCTCNT. Ø
OCTSPC, Ø
OCTFIG. 0
M4, -4
C7.
       7
      240
C2402
C260, 260
```

```
1023 DOUBLE WORD OCTAL PRINT ROUTINE
/USES ROUTINE OCTPR
/CALLING: JMS DOCTPR
/HIGH ORDER NUMBER
/LOW ORDER NUMBER
/RETURN AC=0
DOCTPR. Ø
         CLA
         DCA OCTFIG /CLEAR FLAG FIGURE PRINTED
DCA OCTSPC /CLEAR SPACE-COUNTER
TAD I DOCTPR /HIGH ORDER PART
         ISZ DOCTPR
         JMS OCTPRT /PHINT OCTAL TAD I DOCTPR /LOW ORDER PART
         ISZ DOCTPR
                           /PRINT OCTAL
         JMS OCTPRT
         TAD OCTSPC
         CIA
         SNA
                           /SPACES TO PRIT?
         JMP I DOCTPR
                          NO, EXIT
                           YES, NUMBER IS ZERO
         IAC
         DCA OCTSPC
                          /PRINT SPACES
         TAD C240
         JMS PRINT
         ISZ OCTSPC
         JMP •-3
         TAD C260
                          /AND A "0"
         JMS PRINT
         JMP I DOCTPR /EXIT
```

```
/024 SUBROUTINE TRANSLATES TELLX TO ASCIT
/CALL
        :JMS TLXAS WITH TELEX CHARACTER IN AC
        RETURN CHARACTER IS SHIFT
        RETURN WITH ASCII CHARACTER IN AC
/WHO IS TRANSLATED AS $
/? IS TRANSLATAD AS *
/BELL IS TRANSLATED AS ;
TLXAS,
         01
                        ZMASK 5 BITS
        AND C37
        DCA TLXTMP
                        /TEMP . STORAGE
        TAD TLXTMP
        SNA
        JMP TLXOUT
                       /BLANK
        TAD M2
        SNA
        JMP TLXCR
                        /CARRIAGE RETURN
        TAD M6
        SNA
        JMP TLXNL
                        NEW LINE
        TAD M23
        SNA
        JMP TLXSW1
                       /FIGURESHIFT
        TAD M4
        SNA CLA
        JMP TLXSW0
                        /LETTERSHIFT
        TAD TLXTMP
                        /GET CHARACTER AGAIN
        TAD TLXLA
                        /ADD LISTADDRESS
        DCA TLXTMP
                        /TEMP STORAGE
        TAD TLXSW
                        /WHICH SIDE?
        SZA CLA
        JMP TLXRGT
                        /RIGHT SIDE
        TAD I TLXTMP
                        /GET ASCII 6 BIT
        RTR
        RTR
        RTR
        AND C77
                        MASK 6 BIT
TLXMS.
        TAD M40
        SPA
        TAD C100
                       /CHAR<40:300<=CHAR<=337
        TAD C240
                       /CHAR>40:240<=CHAR<=277
TLXOUT, ISZ TLXAS
                       /NORMAL RETURN
        JMP I TLXAS
TLXRGT, TAD I TLXTMP
        JMP TLXMS
TLXSW1, IAC
TLXSWØ, DCA TLXSW
                       /REMEMBER WICH SHIFT
        JMP I TLXAS
                       /RETURN SHIFT
TLXCR
        TAD C215
        JMP ILXOUT
TLXNL
        TAD C212
        JMP TLXOUT
TLXLA, TLXLST
TLXLST. Ø
```

```
2465
                  11
                            5
C37,
         37
         1771
                  10
                           9
                  /SPACE
         4040
         1036
                  /H
                            t
                  /N
         1654
         1556
                  /M
M40,
         - 40
         1451
                  /L
                            )
         2264
                  /R
                            4
                  /G
                            3
         0735
                           8
         1170
                  /I
         2060
                  /P
                           Ø
                  /C
                            :
         Ø372
         2675
                  /V
                           =
                            3
                  /E
         0563
         3253
                  12
                           WH 0= $
                  /D
         0477
         Ø252
                  /B
                            ?=*
                            ٠
         2347
                  /S
                            6
         3166
                  /Y
                           C
         0633
                  /F
                  /X
                            /
         3057
                  /A
         0155
                           2
         2762
                  /W
         1273
                  /J
                           BELL=;
C100,
         100
         2567
                  70
                            7
         2161
                  /Q
                            1
                  /K
                            (
         1350
/VARIABLES
TLXTMP,0
TLXSW. 0
/GENERAL CONSTANTS
        -2
M2,
         -4
M40
M6.
         -6
M23.
         -23
C77,
         77
         212
C212,
         215
C215,
         240
C240,
```

```
2025 SUFFOUTING TO THANSLATE TELEX CHAR TO ASCII
        JMS TLXAS1
/CALL:
        RETURN IF SHIFT CHARACTER
1
        RETURN
TLXASI, Ø
        AND TLX37
        DCA TLXTMP
                          /STORE
        TAD TLXTMP
        TAD TLXM37
        SNA
                          /LETTERSHIFT?
                          /YES, SET SHIFT
        JMP TLXLSH
        TAD C4
        SNA CLA
                          /FIGURESHIFT?
                          MYES, CLEAR SHIFT
        JMP TLXFSH
        TAD TLXTMP
        TAD TLXSH
        TAD TLXLST
        DCA TLXTMP
        TAD I TLXTMP
        ISZ TLXAS1
        JMP I TLXAS1
TLXLSH, TAD TLX40
TLXFSH, DCA TLXSH
        JMP I TLXAS1
1
1
TLXLST. .+1
                 /BLANK
        0000
        "5
        0215
                 /CR
        "9
        0240
                 /SPACE
        0000
        ",
        ··.
        0212
                 /LF
        ")
        **4
        0000
        **8
        ••ø
        **:
        "=
        "3
        "+
        0205
                 /WRU
        "?
        ** *
        "6
        0000
        "/
        ""_
        911
        0207
                 /BELL
TLXSH,
        Ø
        "7
        ••1
```

```
"(
TLX40.
          40
          0000
          T"
          9215
                    /CE
          ..0
          ••
                    /SPACE
          ••н
          **N
          \bullet \bullet_i \vee_i
                    /LF
          Ø212
          ··L
          "R
          ''G
          ٠٠I
          "P
          "C
          "V
          "E
          "Z
          "B
          "S
          "Y
"F
          ۳X
          "A
          •• 🕡
          "J
TLX37,
          37
          "U
          ••Q
          **K
TLXM37. -37
/VARIABLES
TLXTMP.0
/GENERAL CONSTANTS
/
C4,
          4
```

```
1026 ROUTINE TO TRANSLATE ASCII TO TELEX
/CALL : JMS ASTLX
   RETURN
/BEFORE FIRST CALL INITIALIZE ASTSFT:=4 AND
VPRINT A LETTERSHIFT
VNOT EXISTING CHARACTERS ARE PRINTED AS BLANK
/ALTMODE IS TRANSLATED AS FIGURESHIFT
/BUBOUT IS TRANSLATED AS LETTERSHIFT
ASTLX.
        0
        DCA ASTIMP
                    /TEMP • STORAGE
        TAD ASTIMP
        AND C77
                       MAKE 6 BIT
        SNA
        JMP ASTOUT+2
                       /BLANK=BLANK
        TAD ASTLA
                       /LISTADDRESS
        DCA ASTHLP
                       /LISTADDRESS + 6-BIT CHAR
        TAD ASTIMP
       TAD M300
        SMA CLA
                     /CHAR>=300; RIGHT HALF OF LIST
        JMP ASTBIG
        TAD I ASTHLP
                     /CHAR<300; LEFT HALF OF LIST
       RTR
       RTR
       RTR
        SKP
ASTBIG, TAD I ASTHLP
       DCA ASTIMP
                      /TEMP • STORAGE
        TAD ASTIMP
       AND C77
        SNA
                      NOT EXISTING IN TELEX: BLANK
       JMP ASTOUT+2
                       /GET SHIFT BIT
       AND C40
       SZA CLA
                       /WHICH SHIFT
       JMP ASTSHF
                      MUST BE FIGURES
       TAD ASTSFT
                      MUST BE LETTERS
       SZA CLA
                      VIS IT LETTERS?
       JMP ASTOUT YES, PRINT CHAR
       CLA CLL IAC RTL /+4; NO, MAKE AND PRINT
ASTPSH, DCA ASTSFT
       TAD ASTSFT
       TAD C33
                       /MAKE SHIFT
       JMS PRINT
                       /PRINT
ASTOUT, TAD ASTIMP
       AND C37
                       MASK 5 BITS
       JMS PRINT
                       PRINT
       JMP I ASTLX
                      /EXIT
ASTSHF, TAD ASTSFT
                      MUST BE FIGURES
       SNA CLA
                       /IS IT FIGURES?
       JMP ASTOUT
                      YES, PRINT CHAR
       JMP ASTPSH
                      /NO, MAKE AND PRINT
ASTLA
      ASTLST
ASTLST, 0000
              /@
               /A
       0030
             /B
       0023
```

```
Ø016
          10
          10
0028
6220
          /WHO, E
          /F
0026
7213
          /BELL, G
          /H
0005
0014
          /I
          /NL, J
1032
          /K
0036
          /L
0011
          /CR, M
0207
Ø0Ø6
          /N
0003
          10
          /P
0015
          10
0035
          /R
0012
0024
          15
          /T
0001
0034
          /U
          1V
ØØ17
          1W
0031
0027
          /X
0025
          /Y
          17,
0021
          /[
0000
          / \
0000
0000
          /]
0000
          11
          1-
0000
0400
          /SPACE
0000
          /"
0000
          /#
0000
          19
0000
          1%
0000
          18
0000
          / 1
6400
7600
          /(
5100
          1)
          /*
0000
          /+
6100
4600
          /,
7000
          /-
          /.
4700
6700
          10
5500
7500
          1
          12
7100
          /3
6000
          14
5200
4100
          15
          16
6500
          17
7400
          18
5400
          19
4300
5600
          /:
0000
          /;
```

/<

```
/=, ALTMOD=FIGSHIFT
         5773
                 />
        0000
        6337
                 /?, EUBOUT=LETTEESHIFT
/VARIABLES
ASTSFT.Ø
ASTTMP.0
ASTHLP.0
/GENERAL CONSTANTS
C33,
        33
C37,
        37
C40,
        40
C77,
        77
M300.
        -300
```

```
/027 INTERRUPT OUTPUT HANDLER
/WITH HEAD-TAIL COUPLED BUFFER
/INITIALIZE ONCE BUFIPT:=BUFUET:=BUFFER
/ BUFIBO:=Ø
/CHARACTER HANDLER
/CALL
      : JMS BUFINP WITH CHAR IN AC
       RETURN AC=0
/
BUFINP, 0
                      /TEMP - STORAGE
       DCA BUFTMP
                      /INPTR BEHIND OUTPTR?
        TAD BUFIBO
        SNA CLA
        JMP BUFPUT
                       INO, STORE CHARACTER
        TAD BUFIPT
                       YES
       CIA
        TAD BUFOPT
                       /INPTR = OUTPRT ?
        SNA CLA
       JMP BUFINP+2
                      YES, WAIT FOR PLACE TO STORE
BUFPUT > TAD BUFTMP
                       /NO. GET CHAR
       DCA I BUFIPT
       I-SZ BUFIPT
        TAD BUFBUS
                       /PRINTER BUSY?
        SNA CLA
       6046
                       /NO.INIT WITH AC=0
       IAC
                       YES, SET PRINTER BUSY
       DCA BUFBUS
       TAD BUFIPT
       TAD BUFBND
                       VEND OF BUFFER?
       SZA CLA
       JMP I BUFINP
                      /NO, EXIT
       TAD BUFADR
                       YES, POINTER TO HEAD
       DCA BUFIPT
       IAC
                       /AND SET INPTR BEHIND OUTPTR
       DCA BUFIBO
       JMP I BUFINP
                      /EXIT
```

```
/028 DEVICE INTERRUPT HANDLER
        :JMP PUFOUT /DEVICE INTERRUPT DETECTED!
/CALL
        ROUTINE RETURNS TO INTERHOPT RESTORE "EXIT"
BUFOUT, CLA
                        /CLEAR DEVICE FLAG
        6042
        TAD BULIPT
        CIA
        TAD BUFOPT
                        /INPTR = OUTPTR ?
        SZA CLA
        JMP BUFGET
                        INO, GET CHAR AND PRINT
        TAD BUFIBO
                        /YES, INPTR BEHIND OUTPTR?
        SZA CLA
        JMP BUFGET
                        YYES, GET AND PRINT
        DCA BUFBUS
                        /NO PRINTER READY
        JMP EXIT
BUFGET, TAD I BUFOPT
                       /GET CHAR
        ISZ BUFOPT
        6044 /PRINT CHAR
        CLA
        TAD BUFOPT
        TAD BUFBND /END OF BUFFER?
        SZA CLA
        JMP EXIT
                       /NO, END OF ROUTINE
        TAD BUFADR
                       YES, POINTER TO HEAD
        DCA BUFOPT
        DCA BUFIBO
                       VRESET INPTR BEHIND OUTPTR
                       /END OF HANDLING
        JMP EXIT
/GENERAL INTERRUPT RETURN ROUTINE
        CLA CLL
EXIT.
        TAD LINK
        RAL
                        VRESTORE LINK
        TAD ACCU
                       /RESTORE ACCU
        I ON
                        /INTERRUPT ON
        JMP I Ø
/VARIABLES
BUFTMP,0
BUFIBO, Ø
BUFIPT, 0
BUF OP T. Ø
BUFBUS, Ø
BUFBND, -BUFEND
BUFADR, BUFFER
BUFFER. Ø
*BUFFER+200
BUFEND, Ø
```

```
1929 SUBBOUTINE HEADS OR WRITES DECTAPE
/IN BOTH DIRECTIONS
/CALL
      :JMS DCTAPE
        DEFINING BITS
       BL OCKNUMBER
/
        -# WORDS (12 BITS)
        BUFFERADDRESS-1
       ERROR RETURN OR RETURNADDRESS
       NORMAL RETURN OR RETURNADDRESS
/DEFINING BITS:BIT 0,1,2
                               UNIT NUMBER
                Ø=FORWARD; 1=HEVERSE
       3
        4,5
                0 (NOT USED)
        6,7,8
               MEMORY FIELD
               Ø (NOT USED)
       10
               Ø=DIRECT RETURN; 1=INDIRECT
       11
               \emptyset = READ; 1 = WRITE
DTCA= 6762
DTXA= 6764
DTLB= 6774
DTRA=
       6761
DTSF=
       6771
DTRB=
      6772
DCTAPE. Ø
        CLA
        TAD I DCTAPE
                       /DEFINING BITS
        DCA DCTCOD
                        /SAVE
        ISZ DCTAPE
        TAD DCTCOD
        AND C7400
                        /UNIT# & DIRECTION BIT
        TAD C10
                        /SEARCH MODE
        DTCA DTXA
                        /I/0
        DTLB
                        /CLEAR FIELD REGISTER
        TAD DCTWC
                        /WORD COUNT ADDRESS
        DCA I DCTCA
                        /WORD COUNT:=BLKNR ADDRESS
        TAD C200
                        /GO BIT
DCTCNT, JMS DCTTRN
                        /TURN DECT AND WAIT FOR FLAG
        TAD I DCTWC
                        /READ NUMBER
        CIA
                        /NEG.
                        /NUMBER TO FIND
        TAD I DCTAPE
        SNA
       JMP DCTMAY
                       /FOUND, CHECK DIRECTION
DCTSET, CLL RAL
                       /SAVE SIGN DIFFERENCE
        CLA
        DTRA
       AND C400
                       /DIRECTION BIT
        SNA CLA
        CML
                        /IS FORWARD
        SNL
                       /IS REVERSE
       TAD C400
                       /CHANGE DIRECTION
       JMP DCTCNT
                       /DIRECTION OK, NEXT NUMBER
DCTMAY, TAD DCTCOD
                       /UNIT# & DIRECTION
       AND C400
                       /MASK DIRECTION
       SNA CLA
       JMP DCTRFW
                       MUST BE FORWARD
       DTRA
                       /MUST BE REVERSE
```

```
AND C400
            SZA CLA
           JMP DCTEDR /IS REVERSE, GO READ OR WRITE
JMP DCTCNT /IS FORWARD, CONT SEARCHING
DTRA /MUST BE FORWARD
DCTRFW, DTRA
           AND C400
            SNA CLA
           JMP DCTRDE /IS FORWARD, GO READ OR WRITE
JMP DCTCNT /IS REVERSE, CONT SEARCHING
DCTRDR, ISZ DCTAPE
           TAD I DCTAPE /-# WORDS
DCA I DCTWC /SET WORD COUNT
           ISZ DCTAPE
TAD I DCTAPE /CORE ADDRESS-1
DCA I DCTCA /SET CURRENT ADDRESS
            TAD DCTCOD
           DTLB
                                 /LOAD FIELD BITS
           TAD DCTCOD
           RAR
                                VREAD OR WRITE?
VWRITE
VWRITE
           SZL CLA
TAD C20
           TAD C130
           DTXA
           DTSF DTRB
           JMP •-1
           ISZ DCTAPE /ADVANCE TO ERRORRETURN
SMA CLA /SKIP IF ERROR
ISZ DCTAPE /NORMAL RETURN
TAD DCTCOD /DIRECT OR INDIRECT?
           RTR
           SNL CLA
           SNL CLA

JMP •+3 /DIRECT

TAD I DCTAPE /INDIRECT, PREPARE
           DCA DCTAPE
           DTRA
           AND C200 /GO BIT
TAD C2 /PRSERVE ERROR FLAG
DTXA /STOP TAPE
JMP I DCTAPE /READY, EXIT
DCTTEN. Ø
           DTXA
           DTSF DTRB
           JMP •-1
           SPA
           JMP DCTERR
           CLA
           JMP I DCTTRN
DCTERR, RTL
           RAL
           CLA CML
           SNL.
           TAD C400
           JMP DCTCNT-1
```

```
/VARIABLES
DCTCOD. Ø
DCTWC, 7754
DCTCA, 7755
/GENERAL CONSTANTS
/
cs,
         2
C10,
         10
CSØ,
         2Ø
C130,
         130
C200.
         200
C400.
        400
C7400, 7400
```

```
/030 SUBROUTINE TO PACK CHARACTERS (TSS8)
/THREE CHARACTERS IN TWO WORDS (TSS8 FORMAT)
/PACKED:111111112222
    222233333333
/
/CALL : JMS PACK
        ADDRESS INPUTBUFFER
       ADDRESS OUTPUTBUFFER
       RETURN
/ROUTINE USES AUTO INDEX 10 AND 11
/FORMAT INPUTBUFFER= 1 CHAE/WRD
/LENGTH OUTPUTBUFFER= 200
/LENGTH INPUTBUFFER= 300
PACK
        TAD PCKBFL /-BUFFERLENGTH OUTPUTBUFFER
        STL PAR
                       /DEVIDE BY 2 +
        DCA PCKCNT
        .CLA CMA
                       /-1
        TAD I PACK
                       /ADDRESS INPUTBUFFER
        DCA 10
        ISZ PACK
                       /-1
        CMA
        TAD I PACK
                      /ADDRESS OUPUTBUFFER
        DCA 11
        ISZ PACK
PCKLOP, TAD I 10
                      /GET CHAR
        CLL RTL
        RTL
        DCA PCKTMP
                      /TEMP . STORAGE
        TAD I 10
                      NEXT CHAR
        RTR
        RTR
        DCA PCKTP1
        TAD PCKTP1
        AND C17
        TAD PCKTMP
        DCA I 11
                       /FIRST WORD
        TAD PCKTP1
                       /PICK UP AGAIN
        RAR
        AND C7400
        TAD I 10
                       /NEXT CHAR
        DCA I 11
                       /SECOND WORD
                       /BUFFER FULL ?
        ISZ PCKCNT
        JMP PCKL OP
                       /NO PACK NEXT
        JMP I PACK
                       YES, EXIT
/VARIABLES
PCKCNT. Ø
PCKTMP.0
PCKTP1.0
PCKBFL, -200
/GENERAL CONSTANTS
C17, 17
C7400, 7400
```

```
/031 SUBROUTINE PACKS CHARACTERS ONE BY ONE CISSE)
THREE CHARACTEES IN TWO WOLDS (TSS8 FORMAT)
/PACKED:111111112222
      2222333333333
/
/CALL
        : JMS PCKSGL WITH CHAR IN AC
        ADDRESS OF OUTPUTBUFFER
       RETURN BUFFER FULL
       RETURN NARMAL AC=Ø
/INITIALIZE CE PCKSWT:=0
1
PCKSGL, 0
        ISZ PCKSWT
                      /INITIALIZE?
        JMS PCKINI
                       YES
        DCA I PCKEP
                        INO PUT CHAR IN TEMP BUF
        ISZ PCKEP
                        /INCREMENT POINTER
        ISZ PCKECT
                        /3 CHAR'S IN TEMP BUF?
        JMP PCKNRM
                        /NO, NORMAL EXIT
        JMS PCKRES
                        YES, RESET POINTER TEMP. BUF
        TAD I PCKEP
                        /GET FIRST CHAR
        ISZ PCKEP
        CLL RTL
        RTL
        DCA I PCKPTR
                       /TEMP STORAGE
        TAD I PCKEP
                       /GET SECOND CHAR
        ISZ PCKRP
       RTR
       RTR
        DCA PCKSWT
        TAD PCKSWT
                        /TEMP • STORAGE
                        /MOST SIGN. 4 BITS
        AND C17
        TAD I PCKPTE
        DCA I PCKPTR
                     /FIRST WORD
        ISZ PCKPTR
        TAD PCKSWT
        RAR
       AND C7400
                        /LEAST SIGNIFICANT 4 BITS
        TAD I PCKEP
                        /GET THIRD CHAR
        DCA I PCKPTR
                        /SECOND WORD
        ISZ PCKPTE
        JMS PCKRES
                        VRESET POINTER TEMP BUF
        ISZ PCKCNT
                       /BUFFER FULL?
        JMP PCKNRM
                       N0
        DCA PCKSWT
                       YYES SET SWITCH
        JMP PCKEND
PCKNRM, CMA
        DCA PCKSWT
                       /SET SWITCH
        ISZ PCKSGL
PCKEND, ISZ PCKSGL
       JMP I PCKSGL
PCKINI, Ø
       DCA PCKSWT
                       /TEMP STORAGE
```

```
JMS PCKRES /SET POINTEE TEMP BUF
TAD I PCKSGL /GET BUFFERADDRESS
         DCA PCKPTR
         TAD PCKBFL
         STL RAR
                           /BUFFERSIZE DEVIDED BY 2
         DCA PCKCNT
         TAD PCKSWT
         JMP I PCKINI
PCKRES, Ø
         TAD M3
                         /TEMP BUF IS 3 WORDS
/TEMP BUF ADDRESS
         DCA PCKRCT
         TAD PCKEBA
         DCA PCKRP
         JMP I PCKRES
/VARIABLES
PCKSWT, Ø
PCKPTR.Ø
PCKRP. Ø
PCKECT.0
PCKCNT. Ø
PCKRBA, PCKRB
PCKBFL, -400
PCKRB, Ø
        Ø
        Ø
/GENERAL CONSTANTS
M3, -3
C17, 17
C7400, 7400
```

```
2032 SUBBOUTINE TO PACK CHARACTERS ONE BY ONE (TSS8)
/THREE CHARACTERS IN TWO WORDS (TSS8 FORMAT)
/PACKED:111111112222
    222233333333
/CALL : JMS DSOUT WITH CHAR IN AC
       RETURN BUFFER FULL
        RETURN NORMAL
/INITIALIZE ONCE DSPTR TO BUFFERADDRESS
/AND DSCNT:=DSBFL DEVIDED BY 2
BSW=7002
DSBUF=400
DSOUT.
        DCA DSTMP
                       /TEMP • STORAGE
        RAR
        DCA DSLNK
                        /SAVE LINK
        TAD DSCNTW
                      /FIRST, SECOND OR THIRD CHAR
        CLL RTR
        SNL SMA CLA
        JMP DSFRST /FIRST CHAR OF THREE
        SNL
                      /SECOND CHAR OF THREE
        JMP DSSEC
        TAD DSTMP
                        /THIRD CHAR
        TAD I DSPTR
        DCA I DSPTR
                       /PUT IN BUFFER
        DCA DSCNTW
                        VRESET CHAR COUNT
        ISZ DSPTR
        ISZ DSCNT
                       /BUFFER FULL ?
        JMP DSEX3
                       INO, EXIT
        TAD DSBFA
                        YES, RESET POINTER
        DCA DSPTR
                       /- BUFFERLENGTH
        TAD DSBFL
        STL RAR
                        NDEVIDE BY S
        DCA DSCNT
        TAD DSLNK
                      - PRESTORE LINK
        CLL RAL
        JMP I DSOUT
                       VEXIT BUFFER FULL
DSSEC.
        TAD DSTMP
        CLL RTL
        BSW
                       /BYTE SWAP
        AND C77
        TAD I DSPTR
        DCA I DSPTR
        ISZ DSPTR
        TAD DSTMP
        AND C17
        BSW
        CLL RTL
        DCA I DSPTR
        JMP DSEX2
DSFRST, TAD DSTMP
       CLL RTL
       RTL
       DCA I DSPTR
      ISZ DSCNTW
DSEX2.
DSEX3
       TAD DSLNK
                      VRESTORE LINK
```

```
CLL HAL
ISK DSOUT
JMP I DSOUT /NORMAL EXIT

/
/VARIABLES
/
DSEFL, -400
LSEFA, DSEUF /OUTPUT BUFFER ADDRESS
DSLNR, 0
DSTMP, 0
DSCNTW, 0
DSCNTW, 0
DSPTR, 0
/
/GENERAL CONSTANTS
C17, 17
C77, 77
```

```
/033 SUBROUTINE TO UNPACK CHARACTERS (TSS8)
/PACKED THREE CHARACTERS IN TWO WORDS (TSS8 FORMAT)
/PACKED:111111112222
        2222333333333
/CALL
        :JMS UNPACK
        ADDRESS OF INPUTBUFFEE
        ADDRESS OF OUTPUTBUFFER
        RETURN
/ROUTINE USES AUTO-INDEX 10
UNPACK, Ø
         TAD UNPBFL
                         /-BUFFERLENGTH INPUTBUFFER
         STL RAR
                         NDEVIDE BY S
        DCA UNPCNT
         TAD I UNPACK
                         /ADDRESS INPUTBUFFER
        DCA UNPPIE
        ISZ UNPACK
        CLA CMA
                         1-1
        TAD I UNPACK
                         /ADDRESS OUTPUTBUFFER
        DCA 10
        ISZ UNPACK
UNPLOP, TAD I UNPPTR
        RTR
        RTR
        AND C377
        DCA I 10
                         /FIRST CHAR
        TAD I UNPPTE
                         /PICK UP CHAR AGAIN
        CLL RTL
        RTL
        AND C360
        DCA UNPTMP
                         /TEMP. STORAGE
        ISZ UNPPTR
        TAD I UNPPTR
        CLL RAL
        RTL
        RTL
        AND C17
        TAD UNPTMP
        DCA I 10
                         /SECOND CHAR
        TAD I UNPPTR
        AND C377
        DCA I 10
                         /THIRD CHAR
        ISZ UNPPTR
        ISZ UNPCNT
                         /READY ?
        JMP UNPL OP
                         /NO, CONTINUE
        JMP I UNPACK
                        YES, EXIT
✓VARIABLES
UNPPTR. Ø
UNP TMP, Ø
UNPCNT. Ø
UNPBFL - 400
/GENERAL CONSTANTS
C17,
       17
C360.
        360
C377,
        377
```

```
/034 SUBBOUT! UNPACKS CHARACTERS ONE BY ONE (ISS8)
PACKED THREE CHARACTERS IN TWO WORLS (TSS8 FORMAT)
/PACKED: 111111112222
       2222333333333
       :JMS UNPSGL
/CALL
        ADDRESS INPUTBUFFER
        RETURN BUFFER EMPTY
                               AC=Ø
       NORMAL RETURN AC=CHAR.
/INITIALIZE ONCE UNPRBF:=UNPBEF:=UNPCNT:=0
UNPSGL. Ø
        CLA CLL
        TAD UNPRBF
                       /ARE THERE CHAR'S IN
        SZA CLA
                       /TEMP. BUFFER ?
        JMP UNPGET
                       /YES, GET ONE
                        /NO. INPUTBUFFER EMPTY ?
        TAD UNPBEF
        SZA CLA
        JMP UNPEMP
                       YES, RETURN END OF BUFFER
        TAD UNPCNT
                        /NO OR YES, MUST I
                        /START UP POINTERS ?
        SNA CLA
        JMS UNPINI
                       YES, PLEASE DO
        TAD UNPRBA
                      IN O, JUST UNPACK NEXT WORDS
        DCA UNPRP
        TAD I UNPPTR
                       VNEXT WORD FROM INPUTBUF
        RTE
        RTR
        AND C377
        DCA I UNPRP
                        FIRST CHAR IN TEMP. BUF
        ISZ UNPEP
        TAD I UNPPTE
                        /GET WORD AGAIN
        CLL RTL
        PITL .
        AND C360
        DCA I UNPRP
                        /TEMP . STORAGE
        ISZ UNPPTR
        TAD I UNPPTE
                       VNEXT WORD
        CLL RAL
        RTL
        RTL
        AND C17
        TAD I UNPEP
        DCA I UNPRP
                      /SECOND CHAR
        ISZ UNPRE
        TAD I UNPPTR
                        /THAT WORD AGAIN
        ISZ UNPPTR
        AND C377
        DCA I UNPEP
                        /THIRD CHAR
        TAD UNPERA
                        /RESET POINTER TEMP. BUF
        DCA UNPRP
        CLA CLL CMA RTL /-3
        DCA UNPROT
                   /3 CHAR'S IN TEMP. BUF
        ISZ UNPCNT
                       /INPUTBUFFER EMPTY ?
        JMP UNPGET
                       /NO GET CHAR NOW
                       YYES, SET FLAG BUFFER EMPTY
        IAC
        DCA UNPBEF
                       /AND THAN GET CHAR
UNPGET, ISZ UNPRCT
                       /LAST FROM TEMP. BUF ?
       IAC
                       /NO.SET FLAG
```

```
DCA UNPERF
                       MAS RESET FLAG
        TAD I UNPFP
                       /GET CHAR
        ISZ UNPKP
        ISZ UNPSGL
                        /N ORMAL EXIT
UNPEMT, ISZ UNPSGL
      JMP I UNPSGL
UNPEMP. DCA UNPBEF
                        /RESET FLAG
        JMP UNPEMT
                        /AND EMPTY BUFFER RETURN
UNPINI, Ø
        DCA UNPRBF
                        /RESET FLAG
        TAD I UNPSGL
                        /ADDRESS INPUTBUFFER
        DCA UNPPTR
        TAD UNPBFL
                        /-LENGTH OF BUFFER
        STL RAR
                        VDIVIDE BY 2
        DCA UNPCNT
        JMP I UNPINI
/VARIABLES
UNPBFL, -400'
UNPCNT. Ø
UNPRCT. 0
UNPRP, Ø
UNPPTR.Ø
UNPRBF.0
UNPBEF. Ø
UNPRBA, UNPRB
UNPRB, Ø
       Ø
       0
/GENERAL CONSTANTS
C17, 17
C360.
        360
C377 - 377
```

```
/035 SUBROUTINE TO READ A NAME FROM KEYBOARD
/CALL
       :JMS RDNAME
        WORD 1.2 CHAR'S FROM NAME IN EXCESS-40 CODE
       WORD 2.2 CHAR'S FROM NAME
       WORD 3,2 CHAR'S FROM NAME
VERROR RETURN
/NORMAL RETURN
/ROUTINE USES AUTO INDEX 10, ROUTINES READ, PRINT
/AND CRLF
BSW=7002
BUFADR=400
R DNAME. Ø
        TAD RDNMBF
                       /ADDRESS ASCII BUFFER
        DCA RDPTR
        DCA RDCNT
                       /CHAR. COUNTER
RDIN.
        JMS READ
                        /READ CHAR FROM KEYB.
        DCA RDCHAR
        TAD RDCHAR
        TAD RDMRO
                       /RUBOUT ?
        SNA
        JMP RDROS
                       YES, TO SERVICE
        TAD RDMCRN
                       /NO. CARRIAGE RETURN ?
        SNA
        JMP RDTWNR YES, TO SERVICE
                       NO,LINE FEED
        TAD RDMLFD
        SNA
        JMP RDTWNR
                       YES, SAME SERVICE AS CR
                       /NO, CHAR>240 ?
        TAD RDMSPE
        SPA SNA CLA
        JMP RDFTNM
                       /NO, ERRORRETURN
        TAD RDCHAR
                       YES, IN BUFFER
        DCA I RDPTR
        ISZ RDCNT
                        /+# CHAR'S
        ISZ RDPTR
        JMP RDIN
                       NEXT CHAR
        JMP RDFTNM
                       /4K BUFFER FULL, ERROR
RDROS.
       TAD RDCNT
                       /ALREADY SOMETHING IN BUFFER?
        SNA CLA
        JMP RDIN
                       NO. STUPID RO-TYPER!
        CMA
                        YES COUNTER BACK 1
        TAD RDCNT
        DCA RDCNT
        CMA
                       /AND POINTER BACK 1
        TAD RDPTR
        DCA RDPTR
        TAD I RDPTR
                       ✓PRINT REMOVED CHAR
       JMS PRINT
        JMP RDIN
                       VEND RO-SERVICE
RDTWNR, JMS CRLF
                      PRINT CR LF
        TAD RDCNT
       SNA
       JMP RDFTNM
                       NAME WITHOUT CHAR'S IS RUBBISH
        TAD M6
```

```
SMA SZA
                        /SIX OR LESS CHAR'S
        CLA
                        /MORE, THAN MAKE IT SIX
        TAD C6
        CIA
                        /-# CHAR'S
        DCA RDCNT
        TAD RDNMBF
                        /BUFFER ADDRESS
        DCA RDPTR
        TAD RDNAME
                        /PACKED NAME ADDRESS
        DCA RDTMP
                        VPLACED UNDER CALLING
        TAD RDTMP
        DCA 10
        DCA I 10
        DCA I 10
                        /CLEAR BUFFER
                        MAKE EXCESS-40 CODE
        TAD I RDPTR
EDNXT.
        TAD C240
        AND C77
        BSW
        DCA I RDTMP
        ISZ RDPTR
        ISZ RDCNT
        SKP
                      /READY READING NAME
        JMP RDNMOK
        TAD I RDPTR
                       NOT READY NEXT CHAR
        TAD C240
        AND C77
        TAD I RDTMP
        DCA I RDTMP
        ISZ RDTMP
        ISZ RDPTR
        ISZ RDCNT
        JMP RDNXT
                       /NEXT CHAR'S
RDNMOK, ISZ RDNAME
                       /NORMAL RETURN
RDFTNM, ISZ RDNAME
        ISZ RDNAME
        ISZ RDNAME
        JMP I RDNAME
                       /EXIT
/VARIABLES
RDNMBF, BUFADR /ADDRESS BUFFER
EDPTR. 0
RDCNT. Ø
RDCHAR, Ø
RDTMP. 0
EDMRO, -377
RIMCRN, 377-215
FDMLFD, 215-212
RDMSPE, 212-240
/GENERAL CONSTANTS
M6, -6
C6,
        6
       77
C77,
C240, 240
```

```
/036 SUBROUTINE SEARCHES NAME IN DN-BLOCKS (DISKMON.)
/(DISK MONITOR SYSTEM)
/CALL
      :JMS DNSRC
       NA FIRST TWO CHAR'S IN EXCESS-40 6 BIT
               LAST " " "
       RETURN NAME NOT FOUND
                             AC=Ø
       RETURN NAME FOUND
                              AC=INT. FILE NR
/SUBROUTINE USES AUTO INDEX 11 AND MONITOR DISK HANDLER
BUFFER=400
DNSRC. Ø
                      /# FIRST DN-BLOCK
        TAD C177
        JMS DNSRBK
                      VREAD BLOCK
        TAD I DNSRC
        CIA
        DCA DNSMNA
                      /- TWO CHAR'S OF NAME
       ISZ DNSRC
        TAD I DNSRC
       CIA
       DCA DNSMME
                      /- LAST CHAR'S
       ISZ DNSRC
DNSBLK, CLA CLL IAC RAL /+2
       TAD DNSBFA /BUFFER ADDRESS
       DCA 11
       TAD M31
                      /# ENTRIES IN ONE BLOCK
       DCA DNSCNT
DNSNXT, TAD I 11
                       /FIRST HALF OF NAME
       TAD DNSMNA
                       /COMPARE WITH NAME TO LOOK FOR
       SZA CLA
                       /EQUAL?
       JMP DNSNOT
                       NO TRY NEXT NAME
       TAD I 11
                       YYES, TEST 2ND. HALF TOO
       TAD DNSMME
       SZA CLA
                       /EQUAL?
       JMP DNSNT1
                       INO NEXT NAME
       ISZ 11
       ISZ 11
       TAD I 11
       AND C7
                       /MASK OF INT FILE #
       ISZ DNSRC
DNSERR, JMP I DNSEC
DNSNOT, CLA IAC
DNSNT1, TAD C3
       TAD 11
       DCA 11
       ISZ DNSCNT
                      /END OF THIS BLOCK?
       JMP DNSNXT
                      IN O, COMPARE NEXT NAME
       TAD DNSLNK
                      YES NEXT BLOCK?
       SNA
       JMP DNSERR
                      /NO, NAME NOT FOUND
       JMS DNSRBK
                      /READ THAT BLOCK
       JMP DNSBLK
DNSRBK. 0
       DCA FSTBLK
       TAD C3
```

```
DCA FUNCTI
        TAD DNSBFA
        DCA BUFADR
        DCA DNSLNK
        JMS I SYSIO
                      /MONITOR DISK HANDLER
FUNCTI.0
FSTBLK.Ø
BUFADR. Ø
DNSLNK, Ø
                       /ERROR RETURN
       HLT
       JMP I DNSRBK
/VARIABLES
SYSIO, 7642
DNSMNA.0
DNSMME, Ø
DNSCNT. Ø
DNSBFA, BUFFER
/GENERAL CONSTANTS
C3, 3
       7
C7,
C177, 177
```

M31,

-31

```
/037 SUBROUTINE SEARCHES UNUSED BLOCK ON DISK (DISKMON)
/AND RESERVES IT FOR FILE (DISK MONITOR SYSTEM)
/CALLING: JMS SAMFIL WITH INT. FILE NR IN AC
/ RETURN DISK EULL
       RETURN NORMAL WITH BLOCKNE IN AC
SAMFIL, Ø
        DCA SAMSAV /SAVE INT FILE #
JMS SAMSEC /SEARCH FOR EMPTY
                      /SEARCH FOR EMPTY BLOCK
        JMP I SAMFIL
                      NOT FOUND SO DISK FULL
                      /BLOCKNR STILL IN SAMBKN
        TAD 10 -
                       /AUTO INDEX STILL ON SPOT
        DCA 10
        TAD SAMMSK
                     /WHICH HALF IS MASK
        TAD M77
        SNA CLA
                       /LEFT OR RIGHT?
                      /MASK IS ON RIGHT HALF
        JMP SAMRGT
        TAD SAMSAV
                       /PUT INT FILE # ON LEFT HALF
        CLL RTL
        RTL
        RTL
        DCA SAMSAV
        JMP •+3
SAMRGT, TAD I 10
                      /ADD INT FILE #
        TAD SAMSAV
        DCA SAMSAV
                       /TEMP • STORAGE
        CMA
        TAD 10
        DCA 10
        TAD SAMSAV
                       /PUT IN BUFFER
        DCA I 10
        TAD C5
        DCA FUNCTI
        TAD SAMBFA
        DCA BUFADR
        JMS SAMRDB
                       /RESTORE SAM ON DISK
        ISZ SAMFIL
        TAD SAMBKN
                       /GET BLOCKNR
       JMP I SAMFIL /RETURN
/VARIABLES
SAMSAV, Ø
/GENERAL CONSTANTS
M77, -77
C5.
      5
```

```
ZOS8 SUBFOUTINE SEARCHES INT. FILE # (DISKMON)
/IN SAMBLOCKS (DISK MONITOR SYSTEM)
/CALL :JMS SAMSRC WITH INT. FILE # IN AC
/ RETURN NUMBER NOT FOUND; AC=0
        RETURN OR FOUND, AC=# FIRST BLOCK FROM FILE
/SUBROUTINE USES AUTO INDEX 10 AND MONITOR DISK HANDLER
BUFFER=400
SAMSRC, 0
         DCA SAMIFN /INT FILE # TO SEARCH FOR TAD SAMIFN /MAKE IT TWO IN ONE WORD
         CLL RTL
         RTI.
         RTL
         TAD SAMIFN
         DCA SAMIFN
         DCA SAMBKN
                          /COUNTER FOR BLOCKNE
         TAD C200
                          /# FIRST SAMBLOCK
SAMERK, DCA BLKNE
         TAD C3
                           VREAD FUNCTION
         DCA FUNCTI
         TAD SAMEFA
                          /BUFFER ADDRESS
         DCA BUFADE
         JMS SAMRDB
                         ZEEAD BLOCK
SAMSH, TAD C77
         DCA SAMMSK
                          /SEARCH RIGHT HALF
         1AD M200
         DCA SAMONT
                          /200 WORDS
         CMA
         TAD SAMBFA
         DCA 10
         SKP
SAMNXT, ISZ SAMBKN /COUNT BLOCKNE
         TAD I 10
                          /GET WORD
         AND SAMMSK
                          ZMASK
         CIA
                          /NEGATI V
        DCA SAMIMP /TEMP• STORAGE
TAD SAMIFN /INT FILE # TO SEARCH FOR
AND SAMMSK /MASK CORRECT HALF
TAD SAMIMP /SAME #?
                        /SAME #?
         SNA CLA
        JMP SAMEND /YES, FOUND IT
ISZ SAMENT /NO, MORE IN THIS HALF?
        ISZ SAMONI
JMP SAMNXT
TZ SAMBKN
                         /YES, SEARCH
                          /NO, UPDATE PLOCKNE
         TAD SAMMSK
                          /WHERE WERE WE SEARCHING?
        SZA CLA

JMP •+3

TAD C7700

JMP SAMSR+1

TAB CATTER

ZEFT OR RIGHT HALF

JUNETHALF, BOTH SIDES DONE

ZRIGHT HALF, SO DO LEFT NOW
         AND C7700
         TAD SAMLNK
                         ALAST SAMPLOCK?
         SNA
         JMP SAMNOT
                          YES, SO NOT FOUND
                           INO, READ NEXT BLOCK
         JMP SAMRBK
```

```
SAMEND, ISZ SAMSEC
       TAD SAMBKN
SAMNOT, JMP I SAMSEC
/
SAMEDB, 0
 JMS I SYSIO /MONITOR DISK HANDLER
FUNCTI, 0
             /READ=3, WHITE=5
ELKNR, 0
               ZBLOCKNE
BUFA DR. Ø
               /PUFFERADDRESS
SAMLNK, Ø
               VAR NEXT PLOCK, Ø=LAST BLOCK
       HLT /ERROR RETURN, SYSTEM ERROR
       JMP I SAMEDB
/VARIAPLES
SAMTMP, 0
SAMIFN. 0
SAMBKN.0
SAMMSK, Ø
SAMCNT, 0
SAMBFA, BUFFER
SYSIO, 7642
/GENERAL CONSTANTS
C3,
        3
       77
C77,
C200,
       200
C7700, 7700
M200.
       -200
```

```
/039 SUBROUTINE READS OR WRITES ON DISK (TSS-8)
/BEFORE CALLING CALCULATE DISKADDRESS AND
/PUT IN HIOR AND LOWOR
/CALL : JMS DFILE
        FUNCTION (RFILE OR WFILE)
/
        INTERNAL FILE NUMBER
        -# WORDS
/
        CORE ADDRESS
        ERROR RETURN
       NORMAL RETURN
/FILE MUST BE OPEN !!!!!!!!
DFILE.
         Ø
         TAD I DFILE /GET FUNCTION
         DCA DFINST
         ISZ DFILE
         TAD I DFILE /GET INT. FILE NR
         DCA W6BUF+1
         ISZ DFILE
         TAD I DFILE
                          /-#WORDS
DFTRY.
         DCA W6BUF+2
         ISZ DFILE
         CLA CMA
         TAD I DFILE
                          /CORE ADDRESS
         DCA W6BUF+3
         ISZ DFILE
         TAD W6AD
                          /ADDRESS 6 WORD BUFFER
DFINST, Ø
                         /DO FUNCTION
                          /ERROR WORD
         TAD W6BUF+5
         SNA
                          /NO ERROR
         JMP DFOKE
         CLL RTR
                           /ERR OR
         SZL SNA CLA
         SKP CLA
                           /ERROR=2
         JMP DFERR
                           VERRORIS NOT 2
         IAC
         DCA W2BUF+2
                         /ERROR IS FILE FULL
         TAD WSAD
                          /SO MUST EXTEND FILE
                           VEXTENDING WITH ONE SEGMENT
         EXT
         SZA CLA
         JMP DFERR
                          /ERROR: DISK FULL
         JMP DFERR

TAD DFSEGA

TAD DFSEGA

TAD W2BUF

DCA W6BUF+2

TAD W6BUF+2
         ISZ I W6BUF+2 /INCREMENT COUNTER
         CLL CLA CMA RAL /-2
         TAD DFILE
         DCA DFILE
        JMP DFTRY
                          /GO TRY AGAIN NOW
DFOKE, ISZ DFILE
DFERR, JMP I DFILE
/VARIABLES
DFSEGA, DFSEGØ
                 /# SEGMENTS FILE Ø
DFSEG0.0
```

DESEG1,	(4)	Ze SLGXENTS FILE 1
DFSEG2.3		Z# SEGMENTS FILL 2
DFSEG3.0		/# SEGMENTS FILE 3
W6AD.	W6BUF	
W SA D.	W2BUF	
W6BUF,		
HI OR.	Ø	MIGH ORDER DISK ADDRESS
W2BUF,	Ø	VINT FILE NE
	Ø	/-# WORDS;# SEG'S TO EXT
	Ø	/CORE ADDRESS-1
LOW OFF.	Ø	/LOW ORDER DISK ADDRESS
	Ø	VERROR WORD